



E04-400/900M20S Product Specification

STM32WL33 400/900MHz SoC SMD Wireless Module



Contents

| | |
|---|----|
| Disclaimer and Copyright Notice | 1 |
| 1 Overview | 2 |
| 1.1 Introduction | 2 |
| 1.2 Features | 2 |
| 1.3 Application | 2 |
| 2 Specification parameters | 4 |
| 2.1 RF parameters..... | 4 |
| 2.2 Hardware parameters..... | 4 |
| 2.3 Electrical parameters | 4 |
| 3 Mechanical Dimensions and Pin Definitions | 6 |
| 4 Basic Applications..... | 8 |
| 4.1 Basic Circuit Wiring Diagram | 8 |
| 4.2 ST-LINK programme download/debugging wiring diagram | 8 |
| 5 Basic operations | 9 |
| 5.1 Hardware Designs | 9 |
| 5.2 Software development | 10 |
| 5.2.1 Preparation of tools..... | 10 |
| 5.2.2 SDK package installation | 10 |
| 5.2.3 Engineering Options | 13 |
| 5.2.4 Compiling and Burning | 13 |
| 6 FAQ | 16 |
| 6.1 Unsatisfactory transmission distance..... | 16 |
| 6.2 Modules are vulnerable | 16 |
| 6.3 BER is too high | 16 |
| 7 Welding instructions | 17 |
| 7.1 Reflow temperature | 17 |
| 7.2 Reflow Profile | 17 |
| 8 Related Models..... | 18 |
| 9 Antenna Guide..... | 18 |
| 9.1 Antenna Recommendations | 18 |



| | |
|-------------------------------|----|
| 10 Batch packing method | 20 |
| Revision history | 20 |
| About us | 20 |

Disclaimer and Copyright Notice

The information in this document, including the URL addresses for reference, is subject to change without notice. this document is provided 'as is' without warranty of any kind, including any warranty of merchantability, fitness for a particular purpose, or non-infringement, and any warranty that any proposal, specification, or sample is referred to elsewhere. This document is provided without warranty of any kind, including any warranty of merchantability, fitness for a particular purpose or non-infringement, and any warranty mentioned elsewhere in any proposal, specification or sample. This document does not grant any licence, express or implied, by estoppel or otherwise, to use any intellectual property.

The test data in this document is obtained from tests conducted in the laboratory of EBYTE, and the actual results may vary slightly.

All trade names, trademarks and registered trademarks mentioned herein are the property of their respective owners and are hereby acknowledged.

The final right of interpretation belongs to Chengdu Ebyte Electronic Technology Co.,Ltd.

Notes:


The contents of this manual are subject to change due to product version upgrade or other reasons. Chengdu Ebyte Electronic Technology Co.,Ltd. reserves the right to make changes to the contents of this manual without notice or prompting. EBYTE makes every effort to provide accurate information in this manual, however, EBYTE does not warrant that the contents of this manual are error-free, and all statements, information and recommendations in this manual do not constitute any warranty, express or implied.

1 Overview

1.1 Introduction

E04-400/900M20S is a wireless communication module designed based on STMicroelectronics' newly launched STM32WL33KCV6 (ARM Cortex-M0+) SoC, which is characterised by far-reaching communication, low standby power consumption, strong anti-jamming capability, rich interface resources, strong processing capability and small form factor. It is also suitable for 433/470/868/915MHz band chip wireless module, using industrial-grade high-precision 32.768KHz and 48MHz crystals to ensure the stable operation of the module.

E04-400/900M20S wireless communication module needs user's secondary development, which can be widely used in IOT industry.



1.2 Features

- Ideal conditions for communication distances up to 3.5km;
- Maximum transmit power 20dBm;
- Air Rate: 0.1 ~ 600kbps;
- Supports global licence-free ISM 433/470/868/915MHz bands;
- Modulation: 2(G)FSK, 4(G)FSK, OOK, ASK, D-BPSK, DSSS, I/Q channel data access;
- Supports protocols: W-MBUS, Sigfox, Mioty, KNX-RF, IEEE 802.15.4g, etc;
- Supports 2.8~3.6V power supply, any power supply greater than 3.3V can ensure the best performance;
- The external crystal uses 32.768KHz high-precision industrial-grade crystal and 48MHz active temperature-compensated crystal to ensure the stable operation of the module;
- 14.0*20.0*2.7mm small-size SMD package, facilitating system integration and development;
- Industrial-grade standard design, supporting long time use at -40~+85°C;
- Dual antennas are optional (IPEX/stamp hole), which is convenient for users' secondary development and facilitates system integration development;

1.3 Application

- Smart Cities/Municipal Infrastructure;
- Industrial applications/building automation/power distribution automation;
- Building security systems;

- Smart lighting/street lighting;
- Asset tracking;
- Home energy management systems;
- Smart home and alarm systems;

2 Specification parameters

2.1 RF parameters

| RF parameters | Parameters | Remark |
|----------------------------------|-------------|--|
| E04-400M20S Working Frequency | 413~478 MHz | Supports ISM bands |
| E04-900M20S Working Frequency | 850~930 MHz | Supports ISM bands |
| Transmitting power | 0~20 dBm | The software is adjustable and requires user-developed settings. |
| Receiver sensitivity | -132 dBm | @ 1% BER |
| Communication distance | 3500 meters | Clear and open environment, maximum power, antenna gain 3.5dBi, height 2m, airspeed 1.2kbps. |

2.2 Hardware parameters


| Hardware parameters | Parameters | Remark |
|-------------------------------|------------------------------------|---|
| IC full name | STM32WL33KCV6 | - |
| Core | ARM Cortex-M0+ | - |
| FLASH | 256 KB | - |
| RAM | 32 KB | - |
| Crystal Oscillation frequency | 48MHz/32.768KHz | External crystal; The 48MHz is an active crystal oscillator, and the crystal oscillator power supply control pin is PB1 |
| Size | 14 * 20 mm | - |
| Antenna | IPEX/Stamp Hole | The equivalent impedance is about 50Ω. |
| Communications interface | UART、SPI、I ² C、GPIO、ADC | User-developed settings are required. |
| Package | SMD Stamp Hole | - |
| Weights | 1.2g | ±0.1g |

2.3 Electrical parameters


| Electrical parameters | Minimum Value | Typical Value | Maximum | Unit | Remark |
|-----------------------|---------------|---------------|---------|------|--------|
|-----------------------|---------------|---------------|---------|------|--------|

| | | | Value s | | |
|-----------------------|-----|-----|------------|-------------|---|
| Supply Voltage | 2.8 | 3.3 | 3.6 | V | $\geq 3.3V$ guarantees output power, exceeding 3.6V may damage module |
| Communications Level | - | 3.3 | - | V | Use of 5.0V TTL recommended plus level shifting |
| Transmitting Current | - | 150 | - | mA | Instantaneous power consumption |
| Receiving Current | - | 18 | - | mA | - |
| Sleeping Current | - | 2.5 | - | μA | - |
| Operating Temperature | -40 | 20 | 85 | $^{\circ}C$ | - |
| Operating Humidity | 10 | 60 | 90 | % | - |
| Storage Temperature | -40 | 20 | 125 | $^{\circ}C$ | - |


3 Mechanical Dimensions and Pin Definitions



Top pad :



Bottom pad :



Unit : mm

pad quantity : 30

Tolerance value : X.X±0.2mm


X.XX±0.05mm

| Pin Number | Pin Name | Pin Direction | Pin Usage |
|------------|----------|---------------|--|
| 1 | NC | - | - |
| 2 | NRST | Input | Chip reset trigger input pin, active low |
| 3 | NC | - | - |
| 4 | NC | - | - |
| 5 | NC | - | - |
| 6 | NC | - | - |
| 7 | NC | - | - |
| 8 | PA1 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 9 | PB2 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 10 | NC | - | - |
| 11 | PB0 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 12 | GND | Output | Ground, connected to power reference ground |

| | | | |
|--|------|--------------|--|
| 13 | 3.3V | Input | Power input, support 2.8~3.6V power supply |
| 14 | PA2 | Input/Output | Program debugging/download port SWDIO |
| 15 | PA3 | Input/Output | Program debugging/download port SWCLK |
| 16 | PA0 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 17 | PA11 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 18 | PA10 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 19 | PA9 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 20 | PA8 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 21 | PB15 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 22 | PB14 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 23 | NC | - | - |
| 24 | PB6 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 25 | PB7 | Input/Output | Configurable general-purpose IO ports (see STM32WL33KCV6 manual for details) |
| 26 | NC | - | - |
| 27 | NC | - | - |
| 28 | GND | Output | Ground, connect to power reference ground. |
| 29 | ANT | Output | Antenna connector, stamp hole (50Ω characteristic impedance), to IPEX-1 connector. |
| 30 | GND | Output | Ground, connected to power reference ground |
| Note: The 48MHz module is an active crystal oscillator, and the crystal oscillator power supply control pin is PB1 | | | |

4 Basic Applications


4.1 Basic Circuit Wiring Diagram



Note: Users can develop the general-purpose GPIO ports into relevant function pins according to the requirements.

4.2 ST-LINK programme download/debugging wiring diagram

To download the programme, connect VCC, GND, SWCLK and SWDIO pins.



5 Basic operations

5.1 Hardware Designs

- It is recommended to use a DC regulated power supply to power this module, the power supply ripple factor should be as small as possible, and the module should be reliably grounded;
- Please pay attention to the correct connection of the positive and negative terminals of the power supply, if reversed it may cause permanent damage to the module;
- Please check the power supply to ensure that it is between the recommended supply voltages, if it exceeds the maximum value it may cause permanent damage to the module;
- Check the stability of the power supply to ensure that the voltage does not fluctuate significantly and frequently;
- When designing the power supply circuit for the module, it is often recommended to keep more than 30% of the residual capacity, and the whole machine is conducive to long-term stable operation;
- Modules should be kept as far as possible from power supplies, transformers, high-frequency alignments and other parts with high electromagnetic interference;
- High-frequency digital alignment, high-frequency analogue alignment, power supply alignment must be avoided below the module, if it is really necessary to go through the module below, assuming that the module is welded in the Top Layer, the Top Layer in the contact part of the module to lay the ground copper (all paved with copper and a good ground), it must be close to the digital part of the module and alignment in the Bottom Layer;
- Assuming that the module is soldered or placed in the Top Layer, it is also a mistake to route the wires randomly in the Bottom Layer or any other layer, which will affect the spuriousness of the module as well as the reception sensitivity to varying degrees;
- It is assumed that the module is surrounded by large electromagnetic interference devices will also greatly affect the performance of the module, according to the intensity of the interference is recommended to stay away from the module, if the situation permits you can do appropriate isolation and shielding;
- Assuming that there is a large electromagnetic interference around the module alignment (high-frequency digital, high-frequency analogue, power supply alignment) will also greatly affect the performance of the module, according to the intensity of the interference is recommended to stay away from the module, if the situation permits you can do appropriate isolation and shielding;
- If 5V level is used for the communication line, 1k-5.1k resistors must be connected in series (not recommended, there is still a risk of damage);
- Try to stay away from TTL protocols where part of the physical layer is also 2.4GHz, e.g. USB3.0;
- The antenna mounting structure has a large impact on the module performance, make sure the antenna is exposed, preferably vertically upwards. When the module is installed inside the chassis, a good quality antenna extension cable can be used to extend the antenna to the outside of the chassis;
- The antenna must not be installed inside the metal casing, which will result in a great weakening of the transmission distance.
- If the module is externally connected to an MCU, it is recommended to add a 200R protection resistor to the RXD/TXD of the external MCU.

5.2 Software development


- Software related demo, please download and use it from the official website according to the description of software related guide.
- This document is based on the production of demo synchronous production, used to assist the development of E04-400/900M20S, if the subsequent official SDK has a new use, please follow the official documents.


5.2.1 Preparation of tools

- E04-400/900M20S Module
- ST-LINK V2
- IAR EW for ARM version 8.40.1


5.2.2 SDK package installation

1.Download the SDK package SPIRIT3-DK-Setup-0.9.3.1 and install SPIRIT3-DK-Setup-0.9.3.1.exe.






2.After the installation is completed, the SDK is installed in C:\Users\Administrator\ST (default installation path), after the installation of Navigator and GUI software, which Navigator can be used to describe the SDK, the GUI can be used with the CLI firmware in the SDK for the debugging of RF parameters.




Administrator > ST >

| 名称 | 修改日期 | 类型 | 大小 |
|--------------------------|-----------------|--------------|------------|
| SPIRIT3-DK 0.9.3.1.zip | 2024/3/28 15:44 | 360压缩 ZIP 文件 | 422,087 KB |
| SPIRIT3-DK 0.9.3.1 | 2024/3/28 15:51 | 文件夹 | |
| RF-Flasher Utility 4.3.0 | 2024/3/28 15:50 | 文件夹 | |


3.Go to the installation path, delete the initial SDK package installed (customers can skip this step if they need to develop from scratch), and replace it with the SDK demo version provided by EVERBUILT official website.



4.Install the RF-Flasher Utility-4.3.0.0-Setup.exe downloaded from EVERBUILT official website for burning firmware, the installation path is still C:\Users\Administrator\ST (default installation path).




5.Merge EWARM_SPIRIT3_DFP_Flasher1.0.0.zip under the path C:\Users\Administrator\ST\Flashloaders to the path of IAR.



5.2.3 Engineering Options


1. Go to the SDK installation path, under \Projects\SDK\Library_Examples\EWARM\STEVAL-S38681V1 path, use IAR to open the Library_Examples.eww file.




Note: Only demo routines modified at SDK_BasicGeneric_RX are provided.

5.2.4 Compiling and Burning


1. The compilation is consistent with the normal compilation of IAR, and there are two ways to burn, one is to directly use IAR to select ST-LINK to burn, and the other is to use the previously installed burning software to burn. Under the path of \Projects\SDK\Library_Examples\EWARM\STEVAL-S38681V1\SDK_BasicGeneric_RX\Exe, find SDK_BasicGeneric_RX.bin, this is the firmware we generated and need to burn, open the \RF-Flasher Utility 4.3.3.0. Flasher Utility 4.3.0\Application path under the RF-Flasher_GUI.exe, into the burning tool interface, the burning mode selected for the SWD mode.



2. Select the file to be burned.



3. Click on Flash Burning



At this point, the burn is complete.

6 FAQ

6.1 Unsatisfactory transmission distance

- When there are linear communication barriers, the communication distance will decay accordingly;
- Temperature, humidity, and co-channel interference, which can lead to higher communication packet loss;
- The ground absorbs and reflects radio waves, and the test effect is poorer near the ground;
- Seawater has a strong ability to absorb radio waves, so the effect of the seaside test is poor;
- Metal objects near the antenna, or placed in a metal casing, the signal attenuation will be very serious;
- Wrong power register setting, air rate setting is too high (the higher the air rate, the closer the distance);
- The low voltage of the power supply at room temperature is lower than the recommended value, the lower the voltage, the lower the power generation;
- The antenna used is poorly matched to the module or the antenna itself is of poor quality.

6.2 Modules are vulnerable

- Please check the power supply to ensure that it is between the recommended supply voltages, exceeding the maximum value can cause permanent damage to the module;
- Please check the stability of the power supply, the voltage should not fluctuate significantly and frequently;
- Please ensure that the installation and use of the process of anti-static operation, high-frequency devices electrostatic sensitivity;
- Please ensure that the installation and use of the process of humidity should not be too high, part of the components for humidity-sensitive devices;
- If there is no special demand, it is not recommended to use it under too high or too low temperature.

6.3 BER is too high


- There is interference from the same frequency signal nearby, stay away from the interference source or modify the frequency and channel to avoid interference;
- SPI clock waveform is not standard, check whether there is interference on the SPI line, and the SPI bus line should not be too long;
- The unsatisfactory power supply may also cause garbled code, make sure the reliability of the power supply;
- Poor quality or too long extension cable or feeder cable may also cause high BER.

7 Welding instructions

7.1 Reflow temperature

| Profile Feature | Curve characteristic | Sn-Pb Assembly | Pb-Free Assembly |
|---|-----------------------------------|----------------|------------------|
| Solder Paste | Solder paste | Sn63/Pb37 | Sn96.5/Ag3/Cu0.5 |
| Preheat Temperature min (T _{smin}) | Minimum preheating temperature | 100℃ | 150℃ |
| Preheat temperature max (T _{smax}) | Maximum preheating temperature | 150℃ | 200℃ |
| Preheat Time (T _{smin} to T _{smax})(ts) | Preheating time | 60-120 sec | 60-120 sec |
| Average ramp-up rate(T _{smax} to T _p) | Average rate of increase | 3℃/second max | 3℃/second max |
| Liquidous Temperature (T _L) | Liquid phase temperature | 183℃ | 217℃ |
| Time (t _L) Maintained Above (T _L) | Time above the liquid phase line | 60-90 sec | 30-90 sec |
| Peak temperature (T _p) | Peak temperature | 220-235℃ | 230-250℃ |
| Average ramp-down rate (T _p to T _{smax}) | Average rate of decline | 6℃/second max | 6℃/second max |
| Time 25℃ to peak temperature | Time from 25℃ to peak temperature | 6 minutes max | 8 minutes max |

7.2 Reflow Profile



8 Related Models

| Model | Chip | Carrier frequencies Hz | Transmitting power dBm | Testing Distance km | Package form | Product Size mm | Communications interface |
|-----------------|-------------------|---------------------------|---------------------------|------------------------|--------------|--------------------|------------------------------------|
| E77-400M2 2S | STM32WLE5C CU6 | 433/470M | 22 | 5.6 | SMD | 14*20 | UART、SPI、I ² C、GPIO、ADC |
| E77-900M2 2S | STM32WLE5C CU6 | 868/915M | 22 | 5.6 | SMD | 14*20 | UART、SPI、I ² C、GPIO、ADC |

9 Antenna Guide


9.1 Antenna Recommendations

Antenna is an important role in the communication process, often poor-quality antenna will have a great impact on the communication system, so we recommend some of the antenna as a supporting our wireless module and the performance is more excellent and reasonably priced antenna.

| Model | Type | Frequency Hz | Interface | Gain dBi | Heights mm | Feeders cm | Functional features |
|---------------|---------------------|-----------------|-----------|-------------|---------------|---------------|--|
| TX433-NP-4310 | Flexible Antenna | 433M | Soldered | 2.0 | 43.8*9.5 | - | Built-in flexible, FPC soft antenna |
| TX433-JZ-5 | Glue Stick Antenna | 433M | SMA-J | 2.0 | 52 | - | Ultra Short Straight, Omni-Directional Antenna |
| TX433-JZG-6 | Glue Stick Antenna | 433M | SMA-J | 2.5 | 62 | - | Ultra Short Straight, Omni-Directional Antenna |
| TX433-JW-5 | Glue Stick Antenna | 433M | SMA-J | 2.0 | 50 | - | Bending Rubber Stick, Omni-Directional Antenna |
| TX433-JWG-7 | Glue Stick Antenna | 433M | SMA-J | 2.5 | 75 | - | Bending Rubber Stick, Omni-Directional Antenna |
| TX433-JK-11 | Glue Stick Antenna | 433M | SMA-J | 2.5 | 110 | - | Bendable Rubber Stick, Omnidirectional Antenna |
| TX433-JK-20 | Glue Stick Antenna | 433M | SMA-J | 3.0 | 210 | - | Bendable Rubber Stick, Omnidirectional Antenna |
| TX433-XPL-100 | Suction Cup Antenna | 433M | SMA-J | 3.5 | 185 | 100 | Small Suction Cup Antenna, Cost Effective |

| | | | | | | | |
|----------------|---------------------|----------|--------|-----|-------|-----|--|
| TX433-XP-200 | Suction Cup Antenna | 433M | SMA-J | 4.0 | 190 | 200 | Neutral suction cup antenna, low loss |
| TX433-XP-300 | Suction Cup Antenna | 433M | SMA-J | 6.0 | 965 | 300 | Large suction cup antenna, high gain |
| TX900-FPC-4420 | Flexible Antenna | 868/915M | IPEX-1 | 3.0 | 20*44 | 15 | Built-in flexible, FPC soft antenna |
| TX915-FPC-4510 | Flexible Antenna | 915M | IPEX-1 | 2.0 | 10*45 | 8.5 | Built-in flexible, FPC soft antenna |
| TX915-FPC-8521 | Flexible Antenna | 915M | IPEX-1 | 4.0 | 21*85 | 14 | Built-in flexible, FPC soft antenna |
| TX868-JZ-5 | Glue Stick Antenna | 868M | SMA-J | 2.0 | 52 | - | Ultra Short Straight, Omni-Directional Antenna |
| TX915-JZ-5 | Glue Stick Antenna | 868M | SMA-J | 2.0 | 52 | - | Ultra Short Straight, Omni-Directional Antenna |
| TX868-JKD-20 | Glue Stick Antenna | 868M | SMA-J | 3.0 | 200 | - | Bending Rubber Stick, Omni-Directional Antenna |
| TX915-JKD-20 | Glue Stick Antenna | 915M | SMA-J | 3.5 | 200 | - | Bending Rubber Stick, Omni-Directional Antenna |
| TX915-JKS-20 | Glue Stick Antenna | 915M | SMA-J | 3.0 | 200 | - | Bending Rubber Stick, Omni-Directional Antenna |
| TX868-XPL-100 | Suction Cup Antenna | 868M | SMA-J | 3.5 | 290 | 100 | Small Suction Cup Antenna, Cost Effective |
| TX915-XPL-100 | Suction Cup Antenna | 868M | SMA-J | 3.5 | 260 | 100 | Small Suction Cup Antenna, Cost Effective |

10 Batch packing method



Revision history

| Version | Date | Description | Issued by |
|---------|-----------|--|-----------|
| 1.0 | 2024-5-15 | Initial version | Bin |
| 1.1 | 2025-3-21 | Modify the crystal related description | Bin |

About us

Hot line:4000-330-990

Technical support: support@cdebyte.com

Documents and RF Setting download link: <https://www.ru-ebyte.com>

Thank you for using Ebyte products! Please contact us with any questions or suggestions: info@cdebyte.com

Address: B2 Mould Park, 199# Xiqu Ave, High-tech District, Sichuan, China